

How to reset Booster LLRF Ramp Waveform:

1. Lower Klystron beam current to approx.9 amps
2. Shut off RF drive.
3. Click on"AFG output" stop.
4. Click on"bto4th", choose"bto4th".
5. Click on "AFG store"ram0 and choose ram3.
6. Click on"AFG store"ram3 and choose ram0.
7. Click on store under "AFG store".
8. Click on "AFG output"ram0 and choose ram3.
9. Click on "AFG output"ram3 and choose ram0.
10. Click on start under "AFG output.
11. Turn on RF drive.
12. Raise klystron current to 12.5amps.

Erny Cherbak, RF Group
October 20, 2003