

## MEDM through Citrix/Metis

mlw, 4/05/2013

1. Launch browser window (Internet Explorer or Firefox), go to:  
<https://metis.aps.anl.gov>, login using ANL credentials
2. Optional: Create bookmark for <https://metis.aps.anl.gov>
3. Launch a XenApp Desktop or Remote Desktop Connection
  - a. XenApp Desktop: Click on Desktop tab, click on XenApp Desktop
  - b. Remote Desktop Connection: Click on Remote Desktop icon, enter your APS Desktop computer name to connect to your office PC
4. Set up the Xstart window,  
Start->All Programs->OpenText Exceed->Exceed Tools ->Xstart
5. Use these settings:
  - Method: Secure Shell
  - Host: This will vary
    - For oxygen access, use muon or tin
    - For helios access, use chiron
  - User ID: APS Operations username
  - Password: APS Operations password
  - Command: This will vary
    - Some examples: storage-ring or xfd-display, could also be xterm
6. Test the connection parameters by clicking on the green arrow button at the top of the display
7. If this works then select file->Save as  
Save on the Z: drive
8. Optional: Create a shortcut from the Z: drive file to the desktop